

NOTES:

Not all aircraft panels are equipped with the above instruments. If the instrument is not on the panel the encoder or associated pushbutton will have no function.

Connections: USB 12v Universal power supply Microsoft FSX and X-Plane compatible X-Plane Plug-in included (on CD)

Installation:

Connect USB connector to back of RIC.

The RIC is a USB (HID) device and will self detect in most Windows operating systems when plugged in.

Plug in power supply.

Note: You will need load FSUIPC for advanced functionality when using Flight Simulator